

Code Equivalent for Batteries

AG1 - SR621SW, SR60, SR621, SB-AG/DG, 280-34, T, V364, D364, 602, S621E, GP364, AG1, AG-1, 364, L621, LR621, SG1, LR60, LR620, SW621, GP164, 364X, 364A, AG1/364A, SB-AG, E364

AG2 - SR726SW, SR59, SR726, SB-AL, 280-28, N, V397, D397, 607, S726E, GP397, AG2, AG-2, 397, L726, 397A, 397X, E397

AG3 - SR41W, SR736, SB-B1, 280-13, K, V392, D392, 247D, S736E, AG3, AG-3, GP392, LR736, 392, 192, L736, G3, V3GA, LR41, SG3, ASG3, G3A, V36A, 92A, GP192, 392X, SR41, TR41SW, SR41SW, 247B, SP392, S736S, 392A, 392X, L736H, L736S, SR736PW, RW47, RW47S, GP392-A1, SR41, E392

AG4 - SR626SW, SR66, SR626, SB-AW, 280-39, BA, V377, D377, 606, S626E, GP377, AG4, AG-4, 377, L626, SG4, LR626, LR66, SR628SW, E377, E377CA, LR626SW, 377A, SR262SW, 377X, 377S, GP177, SR626SW, 377/376, E377A, SR66SW, SR625SW, 377BA, CR626SW

AG5 - SR754W, SR48, SR754, SB-B3, F, V393, D393, 255, S754E, GP393, AG5, AG-5, 393, SG5, LR750, LR48, LR754, L750, 393S, 393A, 393X, 393B, D309, 309, D309/393B, SR48SW, V309, RW48

AG6 - SR920SW, SR69, SR921, SB-AN, 280-31, V371, D371, 605, S921E, GP371, AG6, AG-6, 371, CX921, SR290SW, 371, SR69, SG6, LR921, LR920SW, L921, 371A, 371X,

AG7 - SR927W, SR57, SR927, SB-BP/EP, 280-44, W, V399, D399, 613, GP399, 926E, 399, AG7, AG-7, LR927, GR927, SR927SW, CX926, 399X, 399A, SR57H, LR926, SB-BP, SR927PW, SR327W

AG8 - SR1120W, SR55, SR1121, SB-BS/ES, 280-30, L, V391, D391, 609, S1121E, GP391, AG8, AG-8, 391, 191, L1121, G8, VG8GA, LR1120, CA26, V8GS, SG8, 391A, 391X, V8GA, GP191, LR55, SB-BS, SR1120PW, E391

AG9 - SR936SW, SR936, SB-A4, 280-17, V394, D394, 625, 394, GP394, AG9, AG-9, 394, SG9, L936, LR936, SR45, RW33, 394A, 394X, SR936SW, E394

AG10 - SR1130W, SR54, SR1130, SB-BU, 280-15, M, V389, D389, 626, S1131E, GP389, AG10, AG-10, 389, 189, L1131, G10, V10GA, LR1130, GP189, LR54, SG10, A389, L1131, RW89, LR1130S, LR1131, L1131/D, LR1130H, 389A, 389E, 389X, L1133, SR1131, LL1131, LL1131F, L1131F, L1131H, LR1130X, L-1131, SR1130PW, L1130, LH1130, E389

AG11 - SR721SW, SR58, SR721, SB-AK/DK, 280-29, S, V362, D362, 601, S721E, GP362, AG11, AG-11, 362, SG11, 362A, SR720, 362X, 362/361, RW310, L721, LR721, SB-AK, E362

AG12 - 186, 1176A, 186-1, G12A, GP86A, L1142, LR1142, LR43, RW84, V12GA, GP186, L1142F, 10L124, G12-A

AG13 - 1128MP, 1166A, AG13, D76A, G13A, GPA7, GPA76, LR44, LR1154, L1154, PX675A, PX76A, RPX675, S76, V13GA, RW82, KA, A76, 208-904, SB-F9, G13-A, CA18, CA19, LR44, GP76A, L1154H, A-76, AG14, AG-14, KA76, MS76H, CR44, LR44H, L1154G, LR44G, GPS76A, L1154C, L1154F, GPA75, GDA76, A613, LR44GD